

FEA O-Ring installation for old style knobs:

1. Remove knobs using a 2mm allen key for the older style knobs.
2. Install three 1.5 x 6mm o-rings over the pot shaft (see illustration).
3. Push the knob firmly down on the o-ring stack to seat the lower o-ring over the pot threads.
4. Now apply a gentle downward pressure on the o-rings while tightening the knob set screw.
5. If the rotational stiffness is too much then use less downward pressure while tightening the set screw. If you want more stiffness then apply more downward pressure while tightening the set screw.

